



IDEAL NETWORKS

# SignalTEK CT






Quick Reference Guide  
156848 Issue 3

© IDEAL INDUSTRIES Networks Ltd 2018

A subsidiary of IDEAL INDUSTRIES INC.



IDEAL INDUSTRIES, INC.



1	Cable socket	11	ENTER button
2	Ethernet LED	12	Cursor buttons
3	Activity LED	13	Power button
4	Autotest button	14	Battery module
5	DC in connector	15	Charging indicator LED
6	USB socket	16	Link LED
7	Wi-Fi adapter	17	Pass/Fail LED
8	Touchscreen display	18	Saved LED
9	Function buttons	19	Remote autotest button
10	Escape button	20	Battery status LED

Charging Indicator LED (15)	Status
Green	Charging
Off	Charging complete
Flashing	Not charging

Pass/Fail LED (17)	Status
Green	Test passed
Red	Test failed



Battery Status LED (20)	Status
Green (Power ON)	Battery level is sufficient for use
Red (Power ON)	Battery level is low but still operational
Off	Power OFF

## Four Ways to Navigate


A



B




C





Escape - returns to previous screen  
ENTER - accepts selection

D





## Job Setup





# Test Setup







- Cat 3
- Cat 5e
- Cat 6
- Cat 6A
- Cat 7 and 7A
- Cat 8
- USOC8 1 pair
- USOC8 2 pair
- USOC8 3 pair
- USOC8 4 pair
- ETH 1236
- ETH 1278
- PROFINET 4W
- COAX RGxx
- ISDN BRI
- DB
- Custom**
- UTP
- STP
- UTP/STP**
- NONE
- 568A
- 568B**
- USOC
- TERA



# Cable Testing




## Viewing Test Results



# Test Reports

5 tests are saved / memory capacity is 5000 tests



Indicates Wi-Fi is enabled

Select result saving mode

Select current Job

Save the result manually when Auto Save is Off

View result



Select job


Select result



OR Save report to USB

OR Smartphone downloads reports using **IDEAL AnyWARE** app. for Android™ / Apple

TO USB



## Menu Map

