

2-Post Rack — AR200 & AR201

Unpacking and Inspection

Before unpacking:

1. Inspect the carton for damage. If you detect damage, notify the carrier.
2. Remove the components from the carton and inspect them for shipping damage.

Note: The mounting hardware is enclosed in a separate plastic bag located inside one of the packaging inserts glued to the main carton. Remove it before discarding the carton.

Inventory


The following table lists the parts that are included with the NetShelter 2-Post Rack.

Inventory of the NetShelter 2-Post Rack

Component	Quantity
Rack	
3" Extruded Upright Rail	2
1½" × 1½" Extruded Top Angle	2
3½" × 6" Extruded Bottom Angle	2
Hardware	
3/8"-16 × ¾" Hex Head Bolt	12
3/8" Split Lock Washer	12
#12-24 Screw (for installing equipment)	24

Tools Required

You will need a 9/16" box-end wrench to assemble the rack.



face, approxi-
r face of each
her upright.

ase of each
on the small
apped hole
ing the he
rs, as sho

Loc
er

e at the top of
hten only.
peat steps 2-4
tom angles
outward
, tighten

-lb of
ews
in
oc